



RER	11 / 12				15				13				17			
	① Art.-Nr.	③ Art.-Nr.	LG ④ Art.-Nr.	RD ④ Art.-Nr.	① Art.-Nr.	③ Art.-Nr.	LG ④ Art.-Nr.	RD ④ Art.-Nr.	① Art. Nr.	② Art. Nr.	LG ④ Art.-Nr.	RD ④ Art.-Nr.	① Art. Nr.	② Art. Nr.	LG ④ Art.-Nr.	RD ④ Art.-Nr.
0200	63030	11 212	25 618	25 620					63 053	63 074	40 121	40 127	63 053	63 074	40 121	40 127
0225	63031	11 225	25 621	25 623					63 054	63 075	40 122	40 128	63 054	63 075	40 122	40 128
0250	63032	11 242	25 624	25 626					63 055	63 076	40 123	40 129	63 055	63 076	40 123	40 129
0280	63033	11 259	25 627	25 629					63 056	63 077	40 124	40 130	63 056	63 077	40 124	40 130
0315	63034	11 280	25 630	25 632					63 057	63 078	40 125	40 131	63 057	63 078	40 125	40 131
0355	63035	11 298	25 633	25 635					63 058	63 079	40 126	40 132	63 058	63 079	40 126	40 132
0400	63036	11 314	25 636	25 638	63042	11 314	25 636	25 638	63 059	63 080	25 696	25 697	63 059	63 080	25 696	25 697
0450	63037	11 320	25 639	25 641	63043	11 320	25 639	25 641	63 060	63 081	25 698	25 699	63 060	63 081	25 698	25 699
0500	63038	11 322	25 642	25 644	63044	11 322	25 642	25 644	63 061	63 082	25 702	34 826	63 061	63 082	25 702	34 826
0560	63039	11 324	25 645	25 647	63045	11 324	25 645	25 647	63 062	63 083	25 713	25 715	63 062	63 083	25 713	25 715
0630	63040	11 327	25 648	25 650	63046	11 327	25 648	25 650	63 063	63 084	25 720	25 722	63 063	63 084	25 720	25 722
0710	63041	11 330	25 651	25 653	63047	11 330	25 651	25 653	63 064	63 085	25 723	25 725	63 064	63 085	25 723	25 725
0800					63048	11 333	25 654	25 656	63 065	63 086	25 730	25 732	63 065	63 086	25 730	25 732
0900					63049	11 335	25 738	25 740	63 066	63 087	25 737	25 739	63 066	63 087	25 737	25 739
1000					63050	11 337	25 660	25 662	63 067	63 088	25 744	25 746	63 067	63 088	25 744	25 746
1120									63 068	63 089	31187	31186				
1250									63 069	63 090	25066	25065				
1400									63 070	63 091	41813	41814				
1600									63 071	63 092	25767	25769				

Antrieb siehe technisches Datenblatt.
 Belt drive see technical data sheet.
 Entraînement regardez feuille technique.
 Aandrijving zie blad met technische gegevens.
 Drivanordning se tekniskt datablad.
 Drev: se den tekniske dataside.
 Käyttö katso tekninen erittelylehti.
 Accionamiento. Ver la hoja de datos técnicos.
 Tração vide folheto técnico.
 Avviamento: vedi foglio dati tecnici.

A2int-13.03.00-15:44 Bk



RER 11-/12-/15-0200-/1000 RD



RER 13-/17-0200-/1600 RD